



iRobot Roomba 655 Pet Series Filter Replacement

How to remove your dust bin in order to clean it out.

Written By: Matt Davis



INTRODUCTION


It is recommended to empty and clean the dust bin often. This will keep your Roomba at its peak performance.

Step 1 — Filter



- Grasp the back of the Roomba
 - Push the button with your thumb
 - Remove the dust bin by simply pulling out
- ⓘ Be careful not to pull too hard as not to have dust/dirt fall out.

Step 2



- To open the gate, push the yellow tab and pull it open
- Push in the two yellow tabs on the filter and pull it out gently

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 11:17:09 PM.